


WiMi6220T/R Setup



November, 2019


WiMi6220 Operation Modes

TX-AP mode: TX works as an AP (Typical Operation)




RX-AP mode: RX works as an AP

Note: The Relay Server of the RX must be turned ON for the Wi-Fi Streaming to the Wi-Fi devices.




WiMi1000 Repeater Bridge mode: Both TX & RX work as a Station




WiMi6220 Operation Modes


LAN/Station: Station (TX), LAN (RX) mode



LAN/Station: Station mode



Wireless Multicast mode



DIP Switch Configuration

WiMi6220T(Transmitter)



4 bits: Selection of a specific frequency in TX-AP or RX-AP Mode Selection of SSID in WiMi1000 Repeater Bridge Mode

2 bits: Not Used

ENC. Rate 2 bits: Selection of Encoding Bit Rate 2 bits: Selection of Operation Mode

Encoding Rate

ENC. Rate 12 Mbps

ENC. Rate 20 Mbps ENC. Rate 25 Mbps

ENC. Rate Controlled by Web UI

Operation Mode

ENC. Rate | TX-AP

Mode

ENC. Rate RX-AP Mode

ENC. Rate LAN/Station Mode

ENC. Rate **WiMi1000** Repeater Bridge Mode

WiMi6220R(Receiver)



4 bits: Selection of a specific frequency in TX-AP or RX-AP Mode Selection of SSID in WiMi1000 Repeater Bridge Mode

2 bits: Not Used

SYS-ID

2 bits: Selectin of Receiver's ID (Receiver-# in 1:N multicast mode)

2 bits: Selection of Operation Mode

SYS-ID In 1:N

SYS-ID

SYS-ID

SYS-ID

Receiver-3

SYS-ID Receiver-4

Config.

Receiver-1

Receiver-2

SYS-ID

SYS-ID WiMi1000 Repeater

> Bridge Mode

Operation SYS-ID Mode TX-AP Mode

SYS-ID RX-AP Mode

LAN/Station Mode

FCC - WiMi6220T/R Wi-Fi Ch. Selection (TX-AP/RX-AP Mode)




SSID: WiMi6000 00

FCC - SSID Number vs Ch./Frequency Table (TX-AP, RX-AP Mode)

SSID	Ch. No. (Freq.)						
WiMi6000_00	42 (5210)	WiMi6000_04	58 (5290)	WiMi6000_08	122 (5610)	WiMi6000_12	155 (5775)
WiMi6000_01	42 (5210)	WiMi6000_05	106 (5530)	WiMi6000_09	138 (5690)	WiMi6000_13	155 (5775)
WiMi6000_02	42 (5210)	WiMi6000_06	106 (5530)	WiMi6000_10	138 (5690)	WiMi6000_14	155 (5775)
WiMi6000_03	58 (5290)	WiMi6000_07	122 (5610)	WiMi6000_11	138 (5690)	WiMi6000_15	165 (5825)

^{*} SSID for **RX-AP** mode will be **WiMi6000R_XX**.


FCC - WiMi6220T/R SSID Selection (WiMi1000 Repeater Bridge Mode)



^{*} The above DIP switch setting of upper 4-bits must be same with the WiMi1000's SSID setting.

FCC - SSID Number vs Ch./Frequency Table (WiMi1000 Repeater Bridge Mode)


SSID	Ch. No. (Freq. MHz)						
Bridge_00	42 (5210)	Bridge_04	58 (5290)	Bridge_08	122 (5610)	Bridge_12	155 (5775)
Bridge_01	42 (5210)	Bridge_05	106 (5530)	Bridge_09	138 (5690)	Bridge_13	155 (5775)
Bridge_02	42 (5210)	Bridge_06	106 (5530)	Bridge_10	138 (5690)	Bridge_14	155 (5775)
Bridge_03	58 (5290)	Bridge_07	122 (5610)	Bridge_11	138 (5690)	Bridge_15	165 (5825)



^{*} The above DIP switch setting of upper 4-bits on both TX and RX must be same each other.

^{*} The real operating Wi-Fi frequency will be determined by the WiMi1000's SSID setting.

CE - WiMi6220T/R Wi-Fi Ch. Selection (TX-AP/RX-AP Mode)




CE - SSID Number vs Ch./Frequency Table (TX-AP, RX-AP Mode)

SSID	Ch. No. (Freq.)						
WiMi6000E_00	42 (5210)	WiMi6000E_04	58 (5290)	WiMi6000E_08	106 (5530)	WiMi6000E_12	138 (5690)
WiMi6000E_01	42 (5210)	WiMi6000E_05	58 (5290)	WiMi6000E_09	122 (5610)	WiMi6000E_13	138 (5690)
WiMi6000E_02	42 (5210)	WiMi6000E_06	106 (5530)	WiMi6000E_10	122 (5610)	WiMi6000E_14	138 (5690)
WiMi6000E_03	58 (5290)	WiMi6000E_07	106 (5530)	WiMi6000E_11	122 (5610)	WiMi6000E_15	138 (5690)

^{*} SSID for **RX-AP** mode will be **WiMi6000RE_XX**.


CE - WiMi6220T/R SSID Selection (WiMi1000 Repeater Bridge Mode)



^{*} The above DIP switch setting of upper 4-bits must be same with the WiMi1000's SSID setting.

CE - SSID Number vs Ch./Frequency Table (WiMi1000 Repeater Bridge Mode)

SSID	Ch. No. (Freq. MHz)						
BridgeE_00	42 (5210)	BridgeE_04	58 (5290)	BridgeE_08	106 (5530)	BridgeE_12	138 (5690)
BridgeE_01	42 (5210)	BridgeE_05	58 (5290)	BridgeE_09	122 (5610)	BridgeE_13	138 (5690)
BridgeE_02	42 (5210)	BridgeE_06	106 (5530)	BridgeE_10	122 (5610)	BridgeE_14	138 (5690)
BridgeE_03	58 (5290)	BridgeE_07	106 (5530)	BridgeE_11	122 (5610)	BridgeE_15	138 (5690)



^{*} The above DIP switch setting of upper 4-bits on both TX and RX must be same each other.

^{*} The real operating Wi-Fi frequency will be determined by the WiMi1000's SSID setting.

Japan - WiMi6220T/R Wi-Fi Ch. Selection (TX-AP/RX-AP Mode)




SSID: WiMi6000J 00

Japan - SSID Number vs Ch./Frequency Table (TX-AP, RX-AP Mode)

SSID	Ch. No. (Freq.)						
WiMi6000J_00	42 (5210)	WiMi6000J_04	58 (5290)	WiMi6000J_08	106 (5530)	WiMi6000J_12	122 (5610)
WiMi6000J_01	42 (5210)	WiMi6000J_05	58 (5290)	WiMi6000J_09	122 (5610)	WiMi6000J_13	134 (5670)
WiMi6000J_02	42 (5210)	WiMi6000J_06	106 (5530)	WiMi6000J_10	122 (5610)	WiMi6000J_14	134 (5670)
WiMi6000J_03	58 (5290)	WiMi6000J_07	106 (5530)	WiMi6000J_11	122 (5610)	WiMi6000J_15	134 (5670)

^{*} SSID for **RX-AP** mode will be **WiMi6000RJ_XX**.


Japan - WiMi6220T/R SSID Selection (WiMi1000 Repeater Bridge Mode)



^{*} The above DIP switch setting of upper 4-bits must be same with the WiMi1000's SSID setting.

Japan - SSID Number vs Ch./Frequency Table (WiMi1000 Repeater Bridge Mode)

SSID	Ch. No. (Freq. MHz)						
BridgeJ_00	42 (5210)	BridgeJ_04	58 (5290)	BridgeJ_08	106 (5530)	BridgeJ_12	122 (5610)
BridgeJ_01	42 (5210)	BridgeJ_05	58 (5290)	BridgeJ_09	122 (5610)	BridgeJ_13	134 (5670)
BridgeJ_02	42 (5210)	BridgeJ_06	106 (5530)	BridgeJ_10	122 (5610)	BridgeJ_14	134 (5670)
BridgeJ_03	58 (5290)	BridgeJ_07	106 (5530)	BridgeJ_11	122 (5610)	BridgeJ_15	134 (5670)



^{*} The above DIP switch setting of upper 4-bits on both TX and RX must be same each other.

^{*} The real operating Wi-Fi frequency will be determined by the WiMi1000's SSID setting.